



Service Bulletin: 14

Revision: 1

Razor International Pty Ltd, Campbellfield VIC
service@razorinternational.com
1300 555 865

Door Clutch Replacement

Purpose: To ensure the longevity and performance of the door drive.

Reference: Razor Door Drive

Product affected: Razor Door Drive Systems with previous clutch version

Symptom: with ongoing use there maybe wear and tear on the segments of the previous clutch bodies, which the door drives may not be able to drive the door due to the slippery between the clutch and motor. If so, they will need to be replaced with new version clutch mechanism (with rubber grip inside the clutch body)

Procedure:

1. Undo the two off M5 motor bolts as per below image and retain the bolts in the motor
2. Remove the clutch body kit and replace with a new version clutch body kit (P/N: RPD304S)
3. Insert the clutch body kit into door rear housing
4. Bolt the motor assembly into the original position (Torque min 3N.m)

(Important note: Ensure the O-ring is retaining in its motor seat & power lead locates where it originally locates)

