



# Technical Bulletin: 10

## Revision: 1



Razor International Pty Ltd, Campbellfield VIC  
[service@razorinternational.com](mailto:service@razorinternational.com)  
1300 555 865


# Wireless Hybrid Remote Pairing

**Affected Product:** 55-0401 Old style Wireless Hybrid.

## Wireless Pairing:

1. Press and hold blue "CODE" button on the receiver keypad for 2 seconds until blue led illuminates (Blue).



2. Press blue "▲" button on the remote once initially, and then twice. The blue led on receiver keypad will illuminate for 3 seconds (Blue)  and then disappear. This indicates the remote is now keyed.

When Pressing the buttons on remote, LEDs on the receiver keypad indicate as below

- Blue "▲" button-----Yellow
- Green "▼" button ----- Blue
- Red "STOP" button----- Red

## Wireless Unpairing:

To delete the wireless remote, press and hold the blue "CODE" button on receive keypad for 10 seconds, initially indicated by a blue led illuminating, then keep holding the green "MENU" button until all three lights flashing three times  (Yellow + Red + Blue). Then release the button.