


# RAZOR POWER DOOR SYSTEM

Issue date: 2nd Feb, 2018

Connect to  
Trailer Power  
(Refer Note)



Parts List

Item	Description	Part No.
1	Vertical Remote	RCVAP
2	Remote Bezel	RCAPBE
3	Door Drive	PN8C
4	Power kit (Razor)	P-1000R
5	Controller	ECAP14
6	Charge Harness	PN0005E
7	Power harness	PN0001E
8	Battery harness(no fuse)	PN0006E

**Note:** Power is required (9 to 30VDC) to maintain Razor battery. Connect Razor brown wire to Prime mover auxiliary (blue wire). Whites (Razor & Primemover negative) must be connected together